Aerosol Usage Instructions

SmokeCheck® and PurCheck®

To Use: From a distance of 2 to 4 ft. (.6-1.2m) aim spray for 1-2 seconds at the vents or side of the detector. Alarm will sound within 1 to 10 seconds if the detector is functioning properly. Detectors with delay circuits should be sprayed 1 or 2 additional times to activate the alarm.

CoCheck®

To Use:

1. Slide Co-Check® can into Test Head with actuator pointed toward clear plastic bowl.
2. Replace the Can Cap and screw clockwise to tighten until you hear a slight release of aerosol, back of cap counterclockwise approximate 1/2 of a turn.
3. Place VT1 Head (Diag B) around the Carbon Monoxide Tester and push up, actuating the aerosol for approximately 3 to 5 seconds.
4. Leave in place for 10 to 20 seconds or as instructed by manufacturer. If the alarm is functioning properly the alarm will sound.

If detector is functioning properly, your detector should sound within 10 to 25 seconds. (Average response time 12 seconds.)